

ZOSI

WiFi NVR Quick Start Guide


For more information of your new system, please refer to www.zositech.com

V3 .P.02.Z

Contents

EN.....	01
ES.....	10

1 What's in the box



NVR



12V 2A Power Supply



USB Mouse



Ethernet Cable (1m)




HDMI Cable



Quick Start Guide

Note: Products and accessories vary by product models, please refer to the actual product.


2 Introduce the NVR



NOTE: The actual appearance and components may vary with different products, please refer to the actual product.

3 Connection Diagram

- (1) Connect NVR to router using a network cable.
- (2) Connect monitor to the NVR via the HDMI port.
- (3) Connect USB mouse to the USB port on the side panel of NVR.
- (4) Connect NVR to 12V power supply.
- (5) After the system starts, connect IP camera to power supply, and the camera will be automatically paired and connected to the NVR (support 8 cameras max).
- (6) The monitor will show the real-time monitoring picture of the camera.



NOTE: To ensure the device works properly, it is recommended to power on the NVR first for testing before a final installation.

4 Access the System via Smartphone or PC

4.1. Smartphone

Search “Zosi Smart” in the App Store or use a browser to scan the QR code below, download and install the App and follow the instruction to register an account.



Zosi Smart



App(IOS/Android)



App video operation link

4.2. PC

Download path: Go to <https://www.zositech.com/app/>

5 System Settings


5.1. Mouse Operation:

Left Button:

- Preview or Playback Interface: Double-click a single channel to enter full screen and double-click to exit full screen.
- Navigation Menu: Left click to select a menu option.

Right Button:

- Right click to bring up the main menu when the mouse is on the preview interface.
- Navigation Menu: Right click to exit the menu or return to previous menu option.



5.2. Introduce the Menu Bar:

Right-click anywhere on the screen to open the menu bar.



- Single: Select single channel for live viewing
- Multi: Select multi-channel for live viewing
- Start Scan: Start/Stop Scan
- Colour: Adjust colour and image settings
- E-Zoom: E-Zoom the preview interface
- Audio: Adjust the camera volume
- Snap: Snap and save the live view images
- Stop Record: Start/Stop record
- Playback: Search video playback and quick playback
- Intelligent Alarm: Set up Human Detection and Siren-Light Alarm
- IPC Channel Configuration: IPC channel configuration management
- Main Menu: Enter the Main Menu

5.3. System Password:

The factory default username is “admin” and the password is empty, so the first time users can login the system directly.


A login dialog box with a dark blue header containing the word 'Login' and a back arrow icon. Below the header are two text input fields. The first field is labeled 'User Name' and contains the text 'admin'. The second field is labeled 'Password' and is currently empty. At the bottom of the dialog are two buttons: 'Login' and 'Cancel'.

7 Video Playback

Right click the mouse - Playback - Video Playback/Quick Playback,
Video Playback: Playback the video clips via time search or event search.
Quick Playback: Quick playback of the first 30 minutes of video.

The screenshot displays a video search interface with a dark blue background. At the top, there is a 'Search' button and a search icon. Below this, there are three tabs: 'Time Search', 'Event Search', and 'Image'. The 'Time Search' tab is active, showing a 'Start Time' field with the value '17 : 16 : 48'. Below the time field is a grid with 16 rows and 6 columns. The columns are labeled with times: 00:00, 04:00, 08:00, 12:00, 16:00, and 20:00. The first two columns (00:00-04:00 and 04:00-08:00) are shaded blue. To the right of the grid is a calendar for the month of November 2021. The calendar shows the days of the week (Su, Mo, Tu, We, Th, Fr, Sa) and the dates. The date 17 is highlighted in blue. Below the calendar is a grid of checkboxes for each day of the month, with the first 16 days checked.





Previous Video: Play the previous video.

Next Video: Play the next video.


Fast forward: You can play the video clips at 1/4 time speed to 16 times speed.

Rewind: You can rewind the video clips at 1 time speed, 8 times speed, 16 times speed, and 32 times speed.

Screen Modes: Single Channel Playback/Multi-channel Playback. Channels without video playback will show a black screen.

8 Backup

- ① Insert a USB into the USB 2.0 port on the NVR.
- ② Right click the mouse > Main Menu > Backup > Select channels and time period > Search > Select the video clips you want to back up > Click "Apply" .





The device interface would be slightly different from the interface in the video due to different devices. Follow the steps in the video to perform similar operations.

9 Usage Specification

- Use the camera only with compatible ZOSI NVRs.
- Read this guide carefully and keep it for future reference.
- Follow all instructions for safe use of the product and handle with care.
- Use the product within given temperature, humidity, voltage level noted in the device's specifications.
- Do not disassemble the product.
- Use only a regulated power supply with the product (optional). Use of a non-regulated, non-conforming power supply can damage the product and void the warranty.
- Periodic cleaning may be required. Use a damp cloth only. Do not use any harsh, chemical-based cleaners.
- Do not use the product in a sealed, humid environment. It is recommended to place it in a location that is easily ventilated for installation.
- Do not disassemble the device while power is on.

FCC Compliance Statement

This device complies with Part 15 of FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including inference that may cause undesired operation.

Simplified EU Declaration of Conformity


ZOSI declares that the device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.



Correct Disposal of this Product

This marking indicates that this product cannot be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal and promote the sustainable reuse of material resources, please recycle it responsibly. To return your used device, please visit the Return and Collection System or contact the retailer from whom the product was purchased. They can take this product away for environmentally safe recycling.

1 Lista de empaque



NVR



Adaptador de corriente 12V 2A



Ratón



Cable de Ethernet 1m




Cable HDMI



Manual de operación

Nota: El producto y los accesorios varían por diferentes modelos, por favor consulte el producto específico.


2 Introducción del dispositivo



Nota: La apariencia del producto varía por diferentes modelos, por favor consulte el producto específico.

3 Conexión del dispositivo

- (1) Conecte el NVR al enrutador mediante un cable de red.
- (2) Conecte el monitor al NVR a través del puerto HDMI.
- (3) Conecte el ratón a través del puerto USB del panel trasero.
- (4) Conecte el NVR al adaptador de corriente 12V.
- (5) Después de iniciar el sistema, alimente las cámaras y luego se emparejarán con el NVR automáticamente (admite hasta 8 cámaras como máximo).
- (6) Las imágenes se mostrarán en tiempo real en el monitor.



Nota: La apariencia del producto varía por diferentes modelos, por favor consulte el producto específico. Por favor encienda el dispositivo y haga una prueba de su funcionamiento antes de la instalación.

4 Acceso del sistema a través del Móvil inteligente o PC

4.1. Móvil Inteligente

Busque Zosi Smart en App Store o escanee el código QR para descargar e instalar la aplicación. Siga las instrucciones para registrar una cuenta.



Zosi Smart



APP(IOS/Android)



Video de operación de App

4.2. PC

Enlace de descarga: <https://www.zositech.com/pages/app>

5 Configuraciones del sistema

5.1. Operación del ratón:


Botón izquierdo del ratón:

- Interfaz de vista previa o reproducción:
Haga doble clic en único canal para ingresar en la pantalla completa y haga doble clic de nuevo para salir de la pantalla completa.

- Menú de navegación:
Haga clic con el botón izquierdo para seleccionar una opción en el menú.

Botón derecho del ratón:

- Haga clic con el botón derecho para ingresar en el menú principal cuando el ratón esté en la interfaz de vista previa.
- Menú de navegación:
Haga clic con el botón derecho para salir del menú o volver a la opción anterior.



5.2. Introducción del menú:

Haga clic derecho en cualquier lugar de la pantalla para abrir el menú.



- Único: Seleccione un solo canal para vista en vivo
- Múltiples: Seleccione múlti-canales para vista en vivo
- Iniciar escaneo: Iniciar/Detener escaneo
- Color: Ajuste la configuración de color e imagen
- Zoom: Agrande la interfaz de vista previa
- Audio: Ajuste el volumen de la cámara
- Foto: Capture y guarde imágenes de vista en vivo
- Detener la grabación: Iniciar/Detener las grabaciones
- Reproducir: Busque reproducción de video y reproduzca rápidamente
- Alarma inteligente: Configure Detección Humana y Alarma de Sonido&Luz
- Config canal IPC: Gestione la configuración de canal de IPC
- Menú principal: Entre al Menú principal


5.3. Contraseña del sistema:

El nombre de usuario por defecto es "admin" y la contraseña está vacía, así que los usuarios pueden iniciar sesión en el sistema directamente por la primera vez.

A login dialog box titled "Iniciar sesión" with a refresh icon in the top right. It contains two input fields: "Nombre" with the text "admin" and "Contraseña" which is empty. At the bottom are two buttons: "Iniciar sesión" and "Cancelar".

Método de cambiar contraseña: haga clic con el botón derecho del ratón - Menú principal - Configuración - Usuarios - Cambiar contraseña.

NOTA: La nueva contraseña no puede ser menos de 6 caracteres, por favor conserve la contraseña correctamente.



6 Configuración de la fecha y hora

Haga clic con el botón derecho del ratón - Menú principal - Configuración - Básico - Fecha y hora - Elija la hora correspondiente según su región y luego haga clic en "Aplicar" para guardar.

NOTA: El horario predeterminado es GMT, por favor elija la hora correspondiente según su región.



7 Reproducción de vídeos

Haga clic derecho del ratón - Reproducir - Reproducción de video/Reproducción rápida,
Reproducción de video: reproduzca videos a través de la búsqueda de tiempo o la búsqueda de evento.

Reproducción rápida: reproduzca rápidamente los primeros 30 minutos de video.

Buscar

Búsqueda por hora | Búsqueda por evento | Imagen

Comienzo
00 : 00 : 00


	00:00	04:00	08:00	12:00	16:00	20:00
1	■	■	■	■		
2						
3						
4						
5						
6						
7						
8						
9						
10						
11						
12						
13						
14						
15						
16						

2021 11

Su	Mo	Tu	We	Th	Fr	Sa
	1	2	3	4	5	6
7	8	9	10	11	12	13
14	15	16	17	18	19	20
21	22	23	24	25	26	27
28	29	30				

1 2 3 4
 5 6 7 8
 9 10 11 12
 13 14 15 16





Anterior video: reproduzca el video anterior.

Siguiente video: reproduzca el siguiente video.

Avance rápido: puede reproducir videos a una velocidad de 1/4 a 16 veces.

Rebobinar: puede rebobinar videos a una velocidad de 1 vez, 8 veces, 16 veces y 32 veces.

Modos de pantalla: Reproducción de Único Canal/Reproducción Multi-canales. Los canales sin reproducción de video mostrarán una pantalla negra.

8 Copia de seguridad

① Inserte un pendrive USB en el puerto USB 2.0 del NVR WIFI.

② Haga clic derecho del ratón - Menú principal - Copia de seguridad - Elija el canal y el período de tiempo - Buscar - Elija los videos que desea copiar > Haga clic en "Aplicar".

Copia de seguridad

Canal	Comienzo	Final
<input type="checkbox"/> 1	26/09/2019 00:00:00	26/09/2019 00:09:05
<input type="checkbox"/> 2	26/09/2019 00:00:00	26/09/2019 00:04:32
<input type="checkbox"/> 3	26/09/2019 00:00:00	26/09/2019 00:17:46
<input type="checkbox"/> 4	26/09/2019 00:00:01	26/09/2019 00:01:58
<input type="checkbox"/> 4	26/09/2019 00:01:58	26/09/2019 00:29:08
<input type="checkbox"/> 2	26/09/2019 00:04:32	26/09/2019 00:28:36
<input type="checkbox"/> 1	26/09/2019 00:09:05	26/09/2019 00:31:10
<input type="checkbox"/> 3	26/09/2019 00:17:46	26/09/2019 00:36:40
<input type="checkbox"/> 2	26/09/2019 00:28:36	26/09/2019 00:52:45
<input type="checkbox"/> 4	26/09/2019 00:29:08	26/09/2019 00:56:20
<input type="checkbox"/> 1	26/09/2019 00:31:10	26/09/2019 00:53:14
<input type="checkbox"/> 3	26/09/2019 00:36:40	26/09/2019 00:55:32
<input type="checkbox"/> 2	26/09/2019 00:52:45	26/09/2019 01:16:52
<input type="checkbox"/> 1	26/09/2019 00:53:14	26/09/2019 01:15:19
<input type="checkbox"/> 3	26/09/2019 00:55:32	26/09/2019 01:14:26
<input type="checkbox"/> 4	26/09/2019 00:56:20	26/09/2019 01:23:30

1/16 Todos < << >> >

Comienzo 26 / 09 / 2019 00 : 00 : 00

Final 26 / 09 / 2019 23 : 59 : 59

1 2 3 4

Copia de segun Buscar Salida

Para obtener más información sobre la configuración del sistema, por favor visite: <https://bit.ly/3wCeM6n>.



Nota: hay algunas diferencias entre la interfaz de vídeo y la del dispositivo, esto se debe a que los modelos de dispositivos son diferentes, el funcionamiento del sistema es similar, sólo tiene que seguir la operación en el vídeo para configurar.

9 Especificación de uso

- Use cámara con ZOSI NVRs compatibles solamente.
- Lea esta guía detenidamente y consérvela para consultarla en el futuro.
- Siga todas las instrucciones para un uso seguro del producto y manéjelo con cuidado.
- Utilice el producto dentro de la temperatura, la humedad y el nivel de voltaje indicados en las especificaciones del dispositivo.
- No desmonte el producto.
- Use una fuente de alimentación regulada con el producto (opcional) solamente. El uso de una fuente de alimentación no regulada y no conforme puede dañar el producto y anular la garantía.
- Es posible que se requiera una limpieza periódica. Utilice únicamente un paño húmedo. No utilice limpiadores agresivos a base de productos químicos.
- No utilice el producto en un entorno húmedo y sellado. Se recomienda colocarlo en un lugar que sea fácilmente ventilado para su instalación.
- No desmonte el dispositivo mientras esté encendido.

Declaración de Cumplimiento de la FCC

Este dispositivo cumple con la Parte 15 de las Normas de la FCC.

La operación está sujeta a las siguientes dos condiciones:

- (1) Este dispositivo no puede causar interferencias perjudiciales.
- (2) Este dispositivo debe aceptar cualquier interferencia recibida, incluidas las inferencias que puedan provocar una operación no deseada.

Declaración de Conformidad de UE Simplificada

ZOSI declara que el dispositivo cumple con los requisitos esenciales y otras disposiciones relevantes de la Directiva 2014/53/UE.



Eliminación Correcta de este Producto

Esta marca indica que este producto no se puede desechar con otros residuos domésticos en toda la UE. Para evitar posibles daños al medio ambiente o la salud humana por la eliminación descontrolada de desechos y promover la reutilización sostenible de los recursos materiales, recíclelo de manera responsable. Para devolver su dispositivo usado, visite el Sistema de Devolución y Recolección o comuníquese con el minorista donde compró el producto. Pueden llevarse este producto para un reciclaje seguro para el medio ambiente.

ZOSI



www.zositech.com

Support Email: service@zositech.com

Facebook: <https://www.facebook.com/ZosiTechnology/>

Whatsapp: +1-866-841-6932

UK Whatsapp: +86 18675610962

Copyright © 2023 ZOSI Technology Co., Ltd. No part of this publication may be reproduced in any way without the written permission of ZOSI. The information in this publication is believed to be accurate in all respects and ZOSI assumes no responsibility for any consequences arising from the use of its products. As our products are subject to continuous improvement, ZOSI reserves the right to modify product design, specifications and pricing without notice and without any obligation. All rights reserved. ZOSI reserves the right of final interpretation of this manual.



HDMI
HIGH-DEFINITION MULTIMEDIA INTERFACE

F920000Z3007090