


# ZOSI

PROFESSIONAL SECURITY MADE EASY

# Smart


## VIDEO DOORBELL



## Quick Start Guide

For more information of your new system, please refer to [www.zositech.com](http://www.zositech.com)

## Product Drawing-Front



1 Light Sensor

2 Microphone

3 Indicating LED

4 PIR Motion Sensor


5 Infrared LED\*6

6 166° HD Camera

7 Indicating LED

8 Speakers


## Product Drawing-Back



- 9 Reset Button
- 10 Battery Compartment Cover
- 11 AC8V~24V Power Interface
- 12 Micro USB Port For (Battery Charging)

Please remove the battery protector before use.


## Product Drawing-Back



- |    |                |    |                    |
|----|----------------|----|--------------------|
| 13 | Screw Holes*4  | 15 | Mounting Hooks*6   |
| 14 | Wire Terminals | 16 | Power Contact Base |



**Note:** Take apart the baseboard by downward-push it.

# Installation-Brack Installation



**2 Seal Tightly**


**3 Tighten to secure**




**Tighten The Screw**

# Power Supply Solution

## Hard Wire Power Source



## Powered by Battery



# App Download-ToSee



ToSee



Download the app from App Store or Google Play, run the app on your smart phone, and set up the smart video doorbell, following the in-app instructions.


# App User Interface



App Interface




Incoming Call(In-App)




Incoming Call(Backstage)

## Live View Interface



1. Control the scene volume
2. Playback recorded videos
3. Image effect configuration
4. Full screen view
5. Screenshot button
6. Talk to visitor
7. Tap to record on smart phone
8. Back to device list
9. Share the device to other users
10. Setting menu

## Setting Menu



1. Enable/disable power saving
2. LED light on/off switch
3. Enable/disable light sensor
4. Each video Length configuration
5. Motion detection sensitivity configuration
6. Ring volume configuration
7. Intercom volume configuration
8. Format Micro SD card button
9. Device information