

# Security Camera Day/Night

Instruction Manual ---- 1 Mode d'emploi --- 10 Deutsche Anleitung ---- 19 Guía de Instalación ---- 28 Guida rapida all'uso --- 37 Snelstarteids --- 46

#### Statement

Thank you for purchasing this product. ZOSI is committed to providing our customers with a high quality, reliable security solution. ZOSI cannot assume responsibility for any consequences resulting from the use thereof.

## **Before Installation**


This product require cabling. It is strongly suggested to test all products and parts before installation and cabling.


### Installation Video

https://youtu.be/YUf6wVbK0Wk

## **Tech Support**


# **Product Overview**







# **Mounting your camera**

Step 1: Separate the **1** Mounting Plate from **2** Dome Base by twisting the Mounting Plate in a counterclockwise motion.






Step 3: Remove the 3 Dome Cover and 4 Dome.




Step 4: Install the **1** Mounting Plate to the ceiling or wall in the position with the supplied screws.




**Note:** The cable should be though the Mounting Plate.

Step 5: Attach the **4 Dome** and **5 Dome Cover** to the **4 Mounting** Plate.




Step 6: Attach the **② Dome Base** to the **① Mounting Plate**,then twisting Dome Base in a counterclockwise motion until hear the "lock" sound.



Note: The cable should be fixed on the slot hole.

# Positioning the cables

Please note, model shown is for illustration purposes only.



## **Troubleshooting**

- Q: Video Loss appears where the image from my camera should be displaying on my DVR?
- A: 1. Check the extension cable (power and video) is securely connected to the camera.
  - Check the video output from the camera is securely connected to a video input channel on the DVR.
  - 3. Check the power from the camera is securely connected to a power supply.
- Q: When I view an image from the camera at night I only see a bright spot and no image?
- A: A reflection can be caused in night vision mode if the camera is looking through a window. At night, the infrared light the camera uses to see in the dark can 'bounce back' off a reflective surface (such as glass, water, spider webs, some ceramics and so on) and effectively blind the camera. If you want to see outside, mount the camera outside - we made it weatherproof for a reason!
- Q: The BNC extension cable will not connect to my TV?
- A: Many TV's and monitors do not have a BNC connector but do have an RCA connector. Connect a BNC to RCA adapter to the end of the extension cable and then plug into the RCA video input on your TV or monitor.