

Conexión Alexa

Paso 1


Encienda su dispositivo Echo. Luego conecte el dispositivo Echo a una red WiFi disponible. Ingrese la cuenta de Amazon registrada y la contraseña en la página de CUENTA AMAZON y haga clic en INICIAR SESEÓN. Espere a que el dispositivo Echo se cargue y entre en la interfaz principal.



Paso 2

Haga clic en el enlace para crear su cuenta de Amazon e iniciar sesión.


Enlace: <http://alexa.amazon.com>



The image shows a screenshot of the Amazon Alexa sign-in interface. At the top, the Amazon Alexa logo is displayed. Below the logo, the text "Sign-In" is prominently shown. To the right of "Sign-In" is a link for "Forgot password?". The sign-in form consists of two input fields: "Email (phone for mobile accounts)" and "Amazon password". Below these fields are two checkboxes: "Show password" and "Keep me signed in. Details". A large blue button labeled "SIGN-IN" is positioned below the checkboxes. Underneath the button, there is a line of text stating "By continuing, you agree to Amazon's Conditions of Use and Privacy Notice." At the bottom of the page, there is a link for "New to Amazon?" and a button labeled "CREATE A NEW AMAZON ACCOUNT".

Paso 3

(1) Ingrese a la página e inicie sesión, haga clic en Habilidades y busque ZOSI Smart.



(2) Haga clic en HABILITAR, aparecerá la autorización de inicio de sesión.



zosi smart

珠海安士佳电子有限公司

Rated: Guidance Suggested

★★★★★ 12




Share

ENABLE

Account linking required


(3) Autorice y ingrese su cuenta y contraseña de ZOSI Smart, haga clic en INICIAR SESIÓN.

(4) Después del inicio de sesión, saltará a la siguiente página que indica que ZOSI Smart está vinculado correctamente.




The image shows two side-by-side screenshots. The left screenshot is a login page titled "WELCOME". It has two input fields labeled "Account" and "Password", and a green "LOGIN" button. The right screenshot shows the "amazon alexa" logo at the top, followed by a ZOSI logo. Below the logo, it says "zosi smart has been successfully linked." in green. Underneath, it says "What to do next:" followed by a bullet point: "→ Close this window to discover smart-home devices you can control with Alexa."

(5) Haga clic en DESCUBRIR DISPOSITIVOS.



The image shows a dialog box titled "Discover Devices" with a close button (X) in the top right corner. Below the title, it says "Smart Home devices must be discovered before they can be used with Alexa." At the bottom, there are two buttons: a grey "CANCEL" button and a dark blue "DISCOVER DEVICES" button, which is highlighted with a red border.



The image shows a progress bar with the text "Alexa is looking for devices." above it. Below the text, it says "Device discovery can take up to 20 seconds." The progress bar itself is a horizontal bar with a blue segment on the left and a grey segment on the right, indicating the progress of the device discovery process.

