

Quick Operation Guidance

PLUG AND PLAY

Step 1. How to connect DVR to LAN ?

Do it as follow diagram



Unplug modem then connect router and device



①



②



③



④

Note: Before monitoring via smartphone or computer, please ensure your DVR can be connected to internet.

Step 2. How to test your DVR network ?

(1) Right click Mouse - Main menu - Set up - Network,
(2) Tick “Obtain IP address automatically”
(3) Click “Test”,if remind “OK”, that is, connect network successfully.

Note: Please ensure DHCP in your router is open





Step 3. Remote Monitoring

A: Smartphone Remote Monitoring

Appstore QR code

(1) iPhone/iPad User: Search SECU365 in app store and install it, or scan the following QR code to download secu365

Available on the iPhone App Store

Android QR code

(2) Android User: Search SECU365 in google play and install it, or scan the following QR code to download SECU365

ANDROID APP ON Google play

(3) The login interface instruction

Start SECU365 as following



Name: Device name (It is convenient you distinguish the different device)

GID Serial ID in DVR, which can be obtained DVR system menu (Main menu-information-System- Serial ID). It can be input via QR code scaning

User: admin (defaulted, same as DVR system password)

Password: Null(Defaulted, same as DVR system password)

Channel Number DVR channel

Note: If fail to preview surveillance system as above, try to setting a fixed IP address as following

1. Vist your router, and open it as below



2. Find the router subnet mask(for example:255.255.255.0),Preferr ed DNS server(for example: 211.136.192.6), alter DNS Server(for example:114.114.114.114)

3. Input Subnet mask, Preferred DNS server and alter DNS Server in DVR menu accordingly, DVR system menu path is : Main menu – Set up - Network

Note: Please ensure the IP address you input is not used by other device, such as, computer, server, etc.

Click “Test”,if remind “OK”, that is, connect network successfully.



B. IE browser remote monitoring

(1) Please input the website http://www.secu365.net/ on your PC use the IE browse, the page will automatically jump to the picture as the follow



(2) press register as the follow picture



(3) after finish register, please back to http://www.secu365.net , input your information in the login account and login password

3.1 Enter into Tool bar

and select Tools Internet Options to appear the below picture:



3.2 Select Custom level... icon and tick the settings of “ActiveX controls and plug-ins” to enable, details as follows:



3.3 Lastly, after tick all the “Enable”, please click OK to exit. at this moment, you could input IP address to run your program.

3.4 Click" Plugins Download(20150303) ",then download the "anycam.exe" file and run it.

Remind: If the widgets are not downloaded and run successfully, please check if your browser's safety level or firewall setting is too advanced.

Open IE browser to enter into tool Internet Option Internet user-defined level enable widgets.

Downloading and running install widgets need one minute, please wait…patiently.

(4) click the "Devices" button

Device ID: The same you input in your mobile
Device Name: Device name, it is used to distinguish the different device
Device username: It is default admin (same as DVR system paswword)
Device Password: It is default none (same as DVR system paswword)
Channels: DVR channel



(5)Click "live", then it will jump the follow picture



The product features, specifications, pictures, etc. should be subject to real products.
We reserve the rights to modify all of them without notice.